


How To Connect My Epson Printer To My Computer

On this web page, you will find the answer to the query, “How to connect my Epson printer to my computer?” We will also discuss the procedure for installing the Epson printer driver on your computer. Do you wish to know how the above tasks are done? They are extremely simple and easy too. Epson is a highly popular brand, and its printers are known for their fine-quality printouts. These printers are also durable, robust, and efficient. You can make use of the instructions on this page for any model of Epson printer because the steps are pretty much the same. There might be slight differences in the steps for different models. However, the overall procedures for connecting your Epson printer to your computer and installing the driver will be the same.



How Do I Connect My Epson Printer To My Computer?

Yes! We are coming to the answer to the above query. First, make sure that your printer's hardware setup is completed. Confirm that you have turned on your Epson printer and loaded paper into it. Once the hardware installation is over, proceed with the steps below.

Using A USB Connection

Initially, download and install the driver for your printer. To achieve this task, use the instructions given here.

- First of all, access the Epson official website.
- From here, download the driver for your printer (for the respective Operating System).
- Navigate to the Downloads folder on the computer and open the downloaded driver file so that you can install the driver.
- Keep performing the on-screen instructions. Accept the License Agreement.
- When you reach the page with the connection types, choose the option for a USB connection.

Are you done with the above instructions? Splendid! Now, continue with the rest of the steps for a USB connection.

- Get hold of a USB cable to connect your Epson printer to your computer.
- Connect one of the ends of the USB cable to the Epson printer.



- Connect the opposite end of this cable to the USB port on the computer.
- Ensure that the cable is firmly connected at both end ports.
- Finish the remaining on-screen prompts to complete the USB connection.

Using A Wireless Connection

During the printer driver installation, when you land up on the page with the connection types, pick the option for wireless connection.

- Connect your computer to the existing wireless network.
- Make sure that you connect the Epson printer to the same network (to which your computer is connected). You can use any wireless procedure, such as the Wireless Setup Wizard method, the WPS (Wi-Fi Protected Setup) method, etc.
- Bear in mind that if you connect the devices to two different networks, they will not be able to communicate with each other.

- Now, you can start printing from your computer to your Epson printer.



Have You Completed Connecting Your Devices?

Hope you have learned how to connect your Epson printer to your computer. If you stick to the instructions on this page to the T, you can have a successful connection setup. Make sure you follow them in the order given. For further clarifications or answers to your queries, go ahead and contact our technical experts using the call option available on this page.